| Pos. | Quan. | Component name |
|---|---|---|
| 1 | 1 | PTO WHEEL |
| 2 | 1 | PTO SHAFT |
| 3 | 1 | BEARING #1 |
| 4 | 1 | SPACER RING |
| 5 | 1 | BUSHING |
| 6 | 1 | WASHER |
| 7 | 4 | LOW HEAD #63 |
| 8 | 6 | LOW HEAD #68 |
| 9 | 8 | LOW HEAD #27 |
| 10 | 1 | SOLENOID VALVE |
| 11 | 1 | PTO SHAFT LOCK |
| 12 | 1 | BEARING #8 |
| 13 | 1 | OIL FLANGE |
| 14 | 1 | SOCKET SCREW A |
| 15 | 1 | SOCKET SCREW #23 |
| 16 | 1 | PTO FLANGE SAE C |
| 17 | 1 | PTO HOUSE |
| 18 | 1 | PTO CLUTCH |
| 19 | 3 | PISTON RING |
| 20 | 1 | SEEGERRING #25 |
| 21 | 1 | SEEGERRING #24 |
| 22 | 1 | SEEGERRING #33 |