| Pos. | Quan. | Component name |
|---|---|---|
| 1 | 1 | PTO WHEEL |
| 2 | 1 | PTO SHAFT |
| 3 | 1 | BEARING #1 |
| 4 | 1 | COVER PLATE |
| 5 | 4 | LOW HEAD #8 |
| 6 | 6 | LOW HEAD #72 |
| 7 | 4 | LOW HEAD A2 #85 |
| 8 | 8 | LOW HEAD #27 |
| 9 | 1 | PTO SHAFT LOCK |
| 10 | 1 | PTO SHAFT LOCK #2 |
| 11 | 1 | BEARING #8 |
| 12 | 3 | O-RING #2 |
| 13 | 1 | OIL FLANGE |
| 14 | 1 | SOCKET SCREW A |
| 15 | 2 | SOCKET SCREW #23 |
| 16 | 1 | PTO COVER SEALING |
| 17 | 1 | PTO HOUSE |
| 18 | 3 | PISTON RING |
| 19 | 1 | SEEGERRING #25 |
| 20 | 2 | SEEGERRING #24 |
| 21 | 1 | SIMMERING |
| 22 | 1 | WHEEL COUPLING |