

Pos.	Quan.	Component name
1	1	BEARING #1
2	1	BEARING #8
3	1	BUSHING
4	8	LOW HEAD #27
5	4	LOW HEAD #63
6	6	LOW HEAD #68
7	1	OIL FLANGE
8	3	PISTON RING
9	1	PTO CLUTCH
10	1	PTO FLANGE
11	1	PTO HOUSE
12	1	PTO SHAFT
13	1	PTO SHAFT LOCK
14	1	PTO WHEEL
15	1	SEEGERRING #24
16	1	SEEGERRING #25
17	1	SEEGERRING #33
18	1	SOCKET SCREW #23
19	1	SOCKET SCREW A
20	1	SOLENOID VALVE
21	1	SPACER RING
22	1	WASHER