

Pos.	Quan.	Component name
1	1	MUFF COUPLING
2	1	OUTPUT FLANGE
3	1	BEARING #5
4	1	BEARING #6
5	1	COVER THRUST BEARING
6	1	END COVER
7	16	LOW HEAD A1 #5
8	4	LOW HEAD #88
9	22	LOW HEAD #92
10	16	NUT #5
11	2	SIMMERING
12	1	END RING
13	3	STEPSEAL
14	1	OUTPUTSHAFT
15	16	WASHER #9
16	3	WEAR RING
17	1	WHEEL
18	1	PISTON ASSEMBLY